# 15 Watts "stove top" thermoelectric generator

## **Description**

The below is a "stove top" thermoelectric generator for any type of cook stove or pilot flame heat sources. The generator can be just simply placed on the stove to generate 15watts DC electricity by converting the heat source collected from the flame of the stove. The generator is equipped with the outputs of 14 VDC for deep cycle battery charging, and of 12 VDC or 5 VDC for powering electronic products.

The unit is light in weight, small in size, easy to carry for camping.

### Patent No.: ZL 2011 2 0010954.2, ZL 2010 1 0219930.8, ZL 2010 2 0252414.0






Put the generator on top of the heater to generate free electricity

The 8 W generator comes with the wire for the outputs: 12 VDC


car lighter adapter, 4.5V USB, and 13.8V for deep battery charger.

# **Specifications:**

Part Number	TEG-ST15-12V-2	
Output Power	15 Watts	
Output Voltage	12 VDC	
(The car cigarette lighter		
adapter)		
Output Voltage from	> 13.8 VDC	
Charger	> 13.6 VDC	
Maximum Hot Surface	450 ℃	
Temperature		
Dimension Size	220 mm × 200 mm × 156 mm	
Weight	4 kg	



#### How To Use:



The plug  $\Omega$  gives the output of 12 VDC from cigarette lighter socket and 5 VDC from its USB port.

The plug ② gives over 13 VDC for battery charging.

It circulates the hot air for large area heating and save the energy.

#### Instructions in use

- (1) Put the generator on top of stove. About 30 seconds later, the cooling fan of the generator starts running. Wait for 5 minutes till the cooling fan running at full speed. Then you can add the load on the generator.
- (2) How to install and uninstall output wires:

Install:







① Installation Uninstall:

2 Align and insert

③ Clockwise rotate to lock

4 Completed installation









1 Disassemble

② Anticlockwise rotate to unlock

3 Pull out

4 Completed disassemble

#### **Notes**

- (1) The casing temperature will be hot after a while. Do not touch the generator.
- (2) After 30 seconds when the generator is placed on the heat source, please check if the fan starts to rotate. If you do not see the fan start to blow the air. Please take out the generator to check. To remove, hold the handle on the top of the h the generator

# TEG-ST15-12V-2

### **Packing List**

15W "stove top" thermoelectric generator (1)

(2) Cigarette lighter (with USB port)

(3) Battery Charging clip one set

one

#### Serial Number

) Batte	ery Charging clip	one pair
Serial Nu	ımber	
Date		
NO.		
	+\(\)	61,,